



ADEZZ[®]

WE PRODUCE GARDEN PRODUCTS FOR PROFESSIONALS

WATER TABLES



Product description

Our water tables are sure to create an oasis in your garden. The variety of designs and shapes is enormous. Round, square and rectangular shapes are all possible.

All our water tables are equipped with a pump and fountains with LED lighting as standard.

Aluminum water tables can be ordered from stock in RAL7021 and RAL9016, other RAL colours are possible, but take start-up costs into account.

SPECIFICATIONS

General information

Our water tables consist out of:

- Thickness: Corten Steel 3 mm
- Thickness: Aluminium 3 mm
- Including LED-fountains
- 5 year warranty (descending)

Corten

- Brown-orange rust colour
- Delivered un-rusted
- Rust process takes 4-5 months
- BIO rust accelerator available

Aluminum

Stock colours RAL 7021, RAL 9016.

Available in almost any RAL colour (start-up costs apply).

IMPORTANT

Points of attention

- The pH of the water must be neutral (7).
- The products must be unpacked immediately after delivery.
- We only use Corten steel type S355J0WP.
- Coastal areas: We do not recommend using Corten steel within a radius of 2 km from a coastline.
- During the weathering process rust residue can come off the product.
- Drilling / grinding in the material is not permitted.

Maintenance

- **Note!** The LED fountains may become clogged if green waste ends up inside the water table. The fountains are easy to open and clean. After cleaning the fountains, also check the pump for blockage. If clogging happens frequently, place a filter between the pump and the fountains.
- Annual cleaning by removing coarse dirt by with clean tap water.
- Aluminium features must be maintained (cleaning and removing limescale)
- **Note!** Do not use a high-pressure cleaner or abrasive sponge.
- Adezz maintenance products are available (page 5).

PLACEMENT

INSTALLATION

1. Provide a level, solid surface. If not done carefully, this can cause tensions which can result in damage to the product.

2. In case of a solid foundation, make a hole in the foundation under the overflow pipe. This hole functions as a passage of the electrical cables and for draining excess water through the overflow pipe. (The cables from the pump and the fountain lighting exit the water table through the overflow pipe)

3. Place the water table in the desired position.

4. After positioning the water table, now the fountains and pump can be connected to the PVC distribution pipe.

Note! Always open the lid of the water table with at least 2 people! In addition, always use the metal rods supplied with the water table. (See technical drawing on www.adezz.com for specific details regarding the placement of the rods, this may vary per product)

5. Metal rods are missing from smaller and round water tables.

6. Plug the pump into the electrical outlet and check if the fountains are spraying evenly. This can be adjusted inside the water table with the taps on the PVC distribution pipe.




USAGE IN WINTER

- Always remove the plug from the power socket in case of frost
- A pond de-icer is recommended (for sale at any garden centre or DIY store)
- Pump can remain in the water if the above mentioned conditions are met
- You can also remove the pump from the pond and allow it to overwinter under water in a frost-free place


PLACEMENT

WATER TABLE WITH BOWLS

For placing a water table with bowls, the guidelines for placing a normal water table can be used. Follow the instructions below to properly place the bowls on the table.



1. Place the water bowls over the fountains.
2. Bowls can be levelled by means of the levelling screws.
3. Place the rubber O-ring in the indicated position between the water bowl and the body of the fountain.
4. Recommended fountain height is 3cm above the water level, this is adjustable by means of the ball valves in the water table.



Note! When opening the water table, first remove the water bowls!

WATER TABLES

MODELS

For a complete overview of all our products and specifications, please visit www.adezz.com



WATER TABLE CORTEN



WATER TABLE SQUARE CORTEN



WATER TABLE ROUND CORTEN



WATER TABLE ALUMINUM



WATER TABLE SQUARE ALUMINUM



WATER TABLE ROUND ALUMINUM




WATER TABLE WITH BOWLS CORTEN



WATER TABLE WITH BOWLS ALUMINUM

OPTIONS



CUSTOM MADE

ACCESSORIES

ACCESSORIES

All our accessories meet the highest standards and are an highly suitable addition to our products. Visit www.adezz.com for a complete overview of our accessories.



CLEANER & PROTECTOR

We recommend cleaning our products at least twice a year. For optimal results, use the ADEZZ BIO Cleaner & Protector. Always read the descriptions on the packaging carefully before use.



RUST ACCELERATOR

Our Corten Steel products are delivered un-rusted and the weathering process will take approximately 4-5 months. This process can be accelerated with the BIO rust accelerator available on our website. Always read the descriptions on the packaging carefully before use.



DESCALER

We recommend the use of ADEZZ BIO Descaler + to remove limescale from your products. Always read the directions on the packaging carefully before use.



CORTEN VARNISH

Corten varnish can be applied to the Corten Steel products to stop the weathering process. Always read the descriptions on the packaging carefully before use.