

Placement

When installing a fire place, always take the mandatory distances into account as shown.

1. Distance to flammable material without a heat shield.
2. Distance to flammable material with a heat shield.
3. Distance to not flammable material (0 cm).

Fireplaces and accessories with a heat-resistant coating should always be placed under a watertight roof.

